


## TANK CONTENTS INDICATOR/CONTROLLER TYPE DM224

Wiring Diagram for Pressure Transmitter Type PTX 1830 or Type 530 to be read in conjunction with DM224 Installation booklet



This product has been designed and complies to the relevant standards as listed in its certificate of conformity, The installer/user must ensure system compliance Because of continuing development we reserve the right to change the specifications without notice.

HAWKER ELECTRONICS LTD. 57, The Avenue, Rubery Industrial Estate, Birmingham B45 9AL, ENGLAND. Tel: +44(0)121-453-8911 Fax: +44(0)121-453-3777 e mail: info @ hawker- electronics.co.uk

