




FLEXICAP 4-20 TRANSMITTER / FLEXILEVEL 3

Wiring diagram for Flexicap 4 -20 continuous capacitance level transmitter used with Flexilevel 3 Indicator/Controller, to be read in conjunction with Flexicap 4-20 and Flexilevel 3 installation and setting up instructions

For Level control, or High or Low Level Alarm Monitoring



This product has been designed and complies to the relevant standards as listed in its certificate of conformity. The installer/user must ensure system compliance Because of continuing development we reserve the right to change the specification without notice

HAWKER ELECTRONICS LTD

57, The Avenue,
Rubery Industrial Estate,
Birmingham, B45 9AL, England
Telephone :+44(0)121-453-8911 Fax: +44(0)121-453-3777
E.mail: info@hawker-electronics.co.uk



FM 10000



W D 60
Issue D
Oct 21